

Gefen®

8x8 Matrix for HDMI

EXT-HDMI-848

User's Manual



www.gefen.com

ASKING FOR ASSISTANCE

Technical Support:

Telephone (818) 772-9100
(800) 545-6900

Fax (818) 772-9120

Technical Support Hours:

8:00 AM to 5:00 PM Monday thru Friday PST

Write To:

Gefen, LLC
c/o Customer Service
20600 Nordhoff St
Chatsworth, CA 91311

www.gefen.com
support@gefen.com

Notice

Gefen, LLC reserves the right to make changes in the hardware, packaging and any accompanying documentation without prior written notice.

8x8 HDMI Matrix is a trademark of Gefen, LLC

© 2010 Gefen, LLC, All Rights Reserved

All trademarks are the property of their respective owners.

Rev A4

CONTENTS

- 1 Introduction**
- 2 Operation Notes**
- 3 Features**
- 4 8x8 HDMI Matrix Front Panel Layout**
- 5 8x8 HDMI Matrix Front Panel Descriptions**
- 6 8x8 HDMI Matrix Back Panel Layout**
- 7 8x8 HDMI Matrix Back Panel Descriptions**
- 8 EXT-RMT-Matrix-848 Panel Layout**
- 9 EXT-RMT-Matrix-848 Panel Descriptions**
- 10 Connecting And Operating The 8x8 HDMI Matrix**
- 11 8x8 HDMI Matrix Remote Description & Operation**
- 12 RMT-848IR IR Channel Configuration**
- 13 EXT-RMT-Matrix-848 Remote Operation**
- 14 RMT-8-IR IR Channel Configuration**
- 15 RS-232 Serial Control Interface**
- 16 Network Cable Wiring Diagram**
- 17 Appendix A**
- 19 Appendix B**
- 24 Specifications**
- 25 Warranty**

INTRODUCTION

Congratulations on your purchase of the 8x8 HDMI Matrix. Your complete satisfaction is very important to us.

Gefen

Gefen delivers innovative, progressive computer and electronics add-on solutions that harness integration, extension, distribution and conversion technologies. Gefen's reliable, plug-and-play products supplement cross-platform computer systems, professional audio/video environments and HDTV systems of all sizes with hard-working solutions that are easy to implement and simple to operate.

The Gefen 8x8 Matrix

Now you can easily combine eight cross-platform computers and eight digital displays without networking. Our 8x8 HDMI Matrix provides a simple, reliable and highly effective method of creating multiple computer workstations, with each workstation capable of accessing any one of the computers or sources at any time by remote control. You also have the option of setting up the eight stations locally or extending them with a Gefen extender.

How It Works

The 8x8 Matrix has eight HDMI inputs and eight HDMI outputs. You simply connect your eight computer HDMI ports to the 8x8 Matrix inputs, then connect your eight HDMI displays to the 8x8 Matrix outputs.

OPERATION NOTES

READ THESE NOTES BEFORE INSTALLING OR OPERATING THE 8X8 HDMI MATRIX

- The 8x8 HDMI Matrix is HDCP compliant when used in EDID pass-through mode (when a single HDMI input is mapped to a single HDMI output). Additional Matrix outputs which attempt to route video signals to a source device that has already made an HDCP connection with an HDCP-compliant display will not be able to display an image.
- By default, EDID routing is based on the first connected source and display.

For example, if monitor A is the first display to connect to source 1 its EDID will be used. All other displays that connect to source 1 thereafter will have its EDID ignored. If display 1 switches to another source a hot-plug signal will be sent and the EDID from the next display that is connected, in numerical order, will be used.
- The Status Output display will only list the current display/source routing.
- There is no internal scaling in the 8x8 HDMI Matrix. All of the attached monitors must be able to display the resolutions output by the source devices. For maximum compatibility it is recommended that only one compatible/common resolution be used by all of the source devices.

FEATURES

Features

- Increases your productivity by providing you with access to eight computers from eight workstations
- Maintains beautiful, sharp HDTV resolutions up to 1080p, 2K, and 1920x1200
- Discrete IR remote control included
- Long-distance remote control at distances of up to 330 feet using optional wired CAT5 cabled remotes
- Serial RS232 port for remote control via computer or a control automation device such as Crestron
- Supports DDWG standards for HDMI monitors.

Package Includes

- (1) 8x8 HDMI Matrix
- (1) RMT-848IR IR Remote Control
- (1) 24V DC Power Supply
- (8) 6-foot HDMI cables
- (1) Rack Ears
- (1) User's Manual

8X8 HDMI MATRIX FRONT PANEL LAYOUT



8X8 HDMI MATRIX FRONT PANEL DESCRIPTIONS

1 LED Status Display

This display will list the current display/source routes.



Monitor Output's are labeled 1 through 8 on the rear panel of the 8x8 HDMI Matrix. These numbers correspond to the letters A through H on the LED Status Display. The top row of letters will remain static while each input number below will represent which source each of the displays are currently viewing.

HPD (Hot Plug Detect)

Whenever a display is connected/disconnected an HPD event will occur. This will be displayed on the LED Status Display. A 2 stage status update will occur whenever a HPD event occurs



1. The first stage will return the HPD status for all outputs. **H** means that the HPD status is HIGH and an **L** indicates that the HPD status is LOW. In the example above, all outputs except for A has an HPD that is LOW, while output A has an HPD that is HIGH.



2. The second stage will return the active monitor status for all outputs. **M** means that a monitor has been detected and an **S** indicates that no monitor is attached or is active. In the example above, all outputs except for A are not detecting a monitor, while output A detects a monitor on its output.


3 IR Receiver

Use the included RMT-848IR remote control to route video to the different displays.

4 Power LED Indicator

This input indicator will become active once the included 24V DC power adapter has been properly connected.

8X8 HDMI MATRIX BACK PANEL LAYOUT



8X8 HDMI MATRIX BACK PANEL DESCRIPTIONS

1-8 ***Optional Remote Switching Ports***

Ports 1 through 8 are used for remote switching using the optional component EXT-RMT-MATRIX-848.

9 ***RS-232 Serial Control Interface***

This port is used for serial communication for multiple functions. Access to certain features are only through the RS-232 interface.

10-17 ***HDMI Input Ports***

Connect up to 8 HDMI sources to HDMI Input Ports 1 through 8.

18-25 ***HDMI Output Ports***

Connect up to 8 HDMI displays to HDMI Output Ports 1 through 8. These output ports correspond to Monitors **A** through **H** on the LED Status Display.

26 ***24V DC Power Input***

Connect the included 24V DC power supply to this input.

27 ***IR Extender mini-jack input***


Connect the optional separately-sold Gefen IR Extender (shown below) to this input to conceal the Matrix and expose only the IR sensor, extend the range of the IR remote, or simply beautify installations by creating a sleek, custom appearance to the A/V setup.



Gefen's IR Extender, part # EXT-RMT-EXTIR

EXT-RMT-MATRIX-848 PANEL LAYOUT

Front Panel



Back Panel



(PRODUCT SOLD SEPARATELY)

EXT-RMT-MATRIX-848 PANEL DESCRIPTIONS

1 Direct Select Buttons

When this unit is attached to a CAT-5 port that corresponds to a display on the 8x8 HDMI Matrix, use buttons 1 through 8 to select what source that display will be viewing. Buttons 1 through 8 directly correspond to HDMI source inputs 1 through 8 on the 8x8 HDMI Matrix.

2 IR Receiver

This port will receive commands from an RMT-8-IR remote control for remote controlled switching at the extended location.

3 Active Input LED Indicator

1 through 8 LED indicators that will visually acknowledge which source is currently selected.

4 CAT-5 Input Port

Connect a CAT-5 cable between this port and the CAT-5 remote switching ports (Item 1 through 8 on page 6) for remote switching.

5 IR Extension Eye

Connect the optional IR Receiver EXTension (part# EXT-RMT-EXTIR) to this port.

6 RS-232 Serial Control Port

This port can be used to control switching via RS-232 serial communication.

CONNECTING AND OPERATING THE 8X8 HDMI MATRIX

How to Connect the 8x8 HDMI Matrix

1. Connect up to 8 HDMI sources to the HDMI Input ports on the 8x8 HDMI Matrix using the supplied HDMI cables.
2. Connect up to 8 HDMI displays to the HDMI Output ports on the 8x8 HDMI Matrix using user supplied HDMI cables.
3. Optionally connect up to 8 remote switching units (Part# EXT-RMT-MATRIX-848) to the RJ-45 Input ports on the rear panel on the 8x8 HDMI Matrix using user supplied CAT-5, CAT-5e or CAT-6.

NOTE: Maximum extension of the EXT-RMT-MATRIX-848 units are 330 Feet (100 Meters).

Operating the 8x8 HDMI Matrix

There are 2 main ways to control the 8x8 HDMI Matrix. Local and remote control. Local control is done using the included RMT-848IR remote control. Remote control is done using the optional EXT-RMT-MATRIX-848 switching units.

Local Control

To control the unit locally, please use the included RMT-848IR remote control. Please see page 12 for usage information.

Remote control

To control the unit remotely, please use the EXT-RMT-MATRIX-848 remote switcher. Each remote switcher has 8 direct select push-buttons that correspond to HDMI inputs 1 through 8. Press the push-button corresponding to the desired source for viewing. There is also the option to use RS-232 switching via the RS-232 port located on the rear panel of the EXT-RMT-MATRIX-848.

8X8 HDMI MATRIX REMOTE DESCRIPTION & OPERATION



Buttons 1 through 8 on the RMT-848IR remote control correspond to display outputs A through H. Buttons 9 through 16 correspond to source inputs 1 through 8. Please use the steps and chart below for instructions on how to route video sources to displays.

Output		Input	
Remote Button	Display	Remote Button	Source
1	A	9	1
2	B	10	2
3	C	11	3
4	D	12	4
5	E	13	5
6	F	14	6
7	G	15	7
8	H	16	8

Routing video to a particular display using the remote control is a 2 step process. The first input step is to select the display (Output column). The second input step is to select the source (Input column) that will be routed to the display that was chosen in the first step. The example below shows how to route input source number 7 to display C.



1. Press the remote button labeled 3 (display C) on the RMT-848IR remote control.
2. Press the remote button labeled 15 (source 7) on the RMT-848IR remote control.
3. The video from HDMI Input 7 should now appear on the display connected to monitor output C.

Repeat these steps to route any video source to any display.

RMT-848IR IR CHANNEL CONFIGURATION


The RMT-848IR remote control has 4 discrete channels for use if the default IR code set conflicts with other remote control commands in your setup. There are 2 DIP Switches underneath the battery on the RMT-848IR remote control. These DIP Switches must match the IR channel in use on the 8x8 HDMI Matrix. The underside of the 8x8 HDMI has multiple banks of DIP Switches. Please see the diagram of the 8x8 HDMI Matrix below for the correct bank and DIP Switches that are used for IR channel configuration. Information on the remaining DIP Switch banks can be found in Appendix A. See below for DIP Switch configurations for each of the available remote channels.

8x8 DVI Matrix DIP Switches




IR CHANNEL CONFIGURATION

RMT-848IR REMOTE CONTROL



8x8 HDMI Matrix




EXT-RMT-MATRIX-848 REMOTE OPERATION



(PRODUCT SOLD SEPARATELY)

Once the EXT-RMT-MATRIX-848 Remote is installed and connected to a remote output port on the 8x8 DVI Matrix, use the direct selection buttons to choose a source to view. Once a source is chosen, its corresponding LED should become active. Optionally, switching can be done using an RMT-8-IR remote control (sold separately) or through the RS-232 serial communications port on the rear panel.



(REMOTE SOLD SEPARATELY)

The RMT-8-IR remote control can be used to select the source that will be displayed on the monitor connected to the EXT-RMT-MATRIX-848.


RMT-8-IR Button	DVI Source
1	1
2	2
3	3
4	4
5	5
6	6
7	7
8	8

RMT-8-IR IR CHANNEL CONFIGURATION


The RMT-8-IR remote control (sold separately) has 4 discrete IR channels for use if the default IR code set conflicts with other remote control commands in your setup. There are 2 DIP Switches underneath the battery compartment cover on the RMT-8-IR remote control that must match DIP Switches on the EXT-RMT-MATRIX-848. There are 4 DIP Switches located on the underside of the EXT-RMT-MATRIX-848. DIP Switches 1 and 2 on the EXT-RMT-MATRIX-848 correspond to DIP Switches 1 and 2 on the RMT-8-IR remote control. See below for DIP Switch configuration of each of the available remote channels.



RMT-8-IR REMOTE CONTROL



EXT-RMT-MATRIX-848



RS-232 SERIAL CONTROL INTERFACE



Only Pins 2 (RX), 3 (TX), and 5 (Ground) are used on the RS-232 serial interface

RS232 Settings

Bits per second 19200

Data bits 8


Parity None

Stop bits 1

Flow Control None


Please see Appendix B for information on the available RS-232 commands.

NETWORK CABLE WIRING DIAGRAM



Gefen has specifically engineered their products to work with the TIA/EIA-568-B specification. Please adhere to the table below when field terminating cable for use with Gefen products. Failure to do so may produce unexpected results and reduced performance.

Pin	Color
1	Orange / White
2	Orange
3	Green / White
4	Blue
5	Blue / White
6	Green
7	Brown / White
8	Brown




CAT-5, CAT-5e, and CAT-6 cabling comes in stranded and solid core types. Gefen recommends using solid core cabling. CAT-6 cable is also recommended for best results.

Each cable run must be one continuous run from one end to the other. No splices or use of punch down blocks.

APPENDIX A

The 8X8 HDMI Matrix has 4 banks of DIP Switches located on the underside of the main unit. This section will outline the function of each DIP Switch bank.

DIP SWITCH BANKS



DIP Switch Bank	Description
A	RMT-848IR channel configuration
B	Monitor Pre-Emphasis
C	EDID Pass Through
D	Individual +5V Enable for Fiber Optic extenders

DIP SWITCH BANK A

DIP Switch	Description
1	RMT-848IR remote control channel configuration. This setting must match DIP Switch 1 on the RMT-848IR remote control.
2	RMT-848IR remote control channel configuration. This setting must match DIP Switch 2 on the RMT-848IR remote control.
3	NOT USED
4	NOT USED
5	NOT USED
6	NOT USED
7	NOT USED
8	General +5V enable on all outputs for use with fiber optic products that require 5V for operation. [OFF] Feature disabled [ON] +5V DC enabled.

APPENDIX A

DIP SWITCH BANK B

DIP Switch	Monitor	Description
1	A	[OFF] 0 db pre-emphasis, [ON] 6 db pre-emphasis
2	B	[OFF] 0 db pre-emphasis, [ON] 6 db pre-emphasis
3	C	[OFF] 0 db pre-emphasis, [ON] 6 db pre-emphasis
4	D	[OFF] 0 db pre-emphasis, [ON] 6 db pre-emphasis
5	E	[OFF] 0 db pre-emphasis, [ON] 6 db pre-emphasis
6	F	[OFF] 0 db pre-emphasis, [ON] 6 db pre-emphasis
7	G	[OFF] 0 db pre-emphasis, [ON] 6 db pre-emphasis
8	H	[OFF] 0 db pre-emphasis, [ON] 6 db pre-emphasis

DIP SWITCH BANK C

DIP Switch	Input	Description
1	1	[OFF] EDID pass-through [ON] EDID set to LOCAL
2	2	[OFF] EDID pass-through [ON] EDID set to LOCAL
3	3	[OFF] EDID pass-through [ON] EDID set to LOCAL
4	4	[OFF] EDID pass-through [ON] EDID set to LOCAL
5	5	[OFF] EDID pass-through [ON] EDID set to LOCAL
6	6	[OFF] EDID pass-through [ON] EDID set to LOCAL
7	7	[OFF] EDID pass-through [ON] EDID set to LOCAL
8	8	[OFF] EDID pass-through [ON] EDID set to LOCAL

DIP SWITCH BANK D

DIP Switch	Input	Description
1	1	[OFF] +5V disabled [ON] +5V enabled
2	2	[OFF] +5V disabled [ON] +5V enabled
3	3	[OFF] +5V disabled [ON] +5V enabled
4	4	[OFF] +5V disabled [ON] +5V enabled
5	5	[OFF] +5V disabled [ON] +5V enabled
6	6	[OFF] +5V disabled [ON] +5V enabled
7	7	[OFF] +5V disabled [ON] +5V enabled
8	8	[OFF] +5V disabled [ON] +5V enabled

EDID MANAGEMENT QUICK START GUIDE

To use EDID Management functions, the EDID mode must be changed from Pass-Through to LOCAL. Please follow the steps below to set this mode.

NOTE: LOCAL EDID mode does not support HDCP.

1. Locate Bank C on the underside of the 8x8 HDMI Matrix.
2. Each input has a DIP switch associated with it. Select the inputs that will be changed to LOCAL mode and flip their DIP switch to the ON position. By default, all DIP switches are in the Pass-Through mode (OFF).

Once the selected inputs are in LOCAL mode an EDID can then be set for each input. Follow the commands below to quickly load an EDID into the LOCAL bank of each input. These instructions use the Windows application Hyperterminal. For details on these and other RS-232 commands please see appendix B.

1. Connect a computer to the 8x8 HDMI Matrix's RS-232 port.
2. Use the RS-232 settings on page 15 to open a connection with the 8x8 HDMI Matrix from the computer using the Hyperterminal application.
3. To store an EDID of a connected display into a LOCAL storage location, type in the following command:

```
#EDIDDSTOLO A 1
```

This example will store the EDID from the monitor connected to output A to input 1. Simply modify the monitor and input characters to route any monitor's EDID to any input's LOCAL storage.

This command supports multiple LOCAL storage parameters. For example, to store the EDID from the monitor connected to the output A to the LOCAL storage locations for all inputs (1 through 8), type the following command:

```
#EDIDDSTOLO A 1 2 3 4 5 6 7 8
```

4. To check the EDID of a connected monitor, type the following command:

```
#PRDSEDID A 1
```

This example will check the EDID from the monitor connected to output A. Simply modify the monitor character (A-H) to check a different output monitor's EDID.

5. To check the EDID stored in any input's LOCAL storage, type the following command:

```
#PRLOEDID 1 1
```

This example will check the EDID that is stored in the LOCAL storage bank for input 1. Simply modify the input character (1-8) to check a different input's stored LOCAL EDID.

APPENDIX B

The 8X8 HDMI Matrix uses RS-232 serial communication for access to a number of features. Please us this section for EDID storing, calling, and routing functions.

REMOTE FUNCTION

The remote functions are used to modify the setting of the product, such as: Input to output routing, EDID memory management etc. These functions are available only via serial communications on the RS-232 port.

HELP FUNCTION

To reference the commands listed in the following pages, simply type HELP and then enter key to display a list of the available commands.

EDID STORAGE LOCATIONS

There are 2 storage locations for EDIDs.

The main storage location is located right in front of each input. These eight locations will transmit an EDID directly to the source devices connected to each input. These eight locations will be referred to as LOCAL in the following section.

The second storage location is an EDID storage bank that can support up to seven EDIDs. Any EDID in this bank can then be uploaded to some or all of the LOCAL EDID storage locations for use by the source devices. This storage location will be referred to as the EDID BANK in the following section.

Modify By Shortcut

Switching Command

First character indicates the output monitor. Second character indicates the input number.

Example: 'A5' routes input 5 to output monitor A

Matrix Status Command

The 'M' or 'm' command will return the current routing state.

Shortcut Routing Command

This command sets the matrix routing state according to a preset routing state. First character is 'S' or 's', second character indicates the state that is set by

function #PSASRS or #MSASRS (please see page 24)

Setting Function Menu

The 'P' or 'p' command will return the settings function menu.

Modify By Function

The syntax for each function is always the same. The '#' character is the start flag followed by the function name in capital letter and a space. The space tells the MCU that the function name is ending. Finally, the parameters required for each function are separated by a space and ending by the '\r' character or "Enter"

APPENDIX B

Example: #FunctionName_param1_param2_param3_param4... \r

Set Preset Routing State

This function enables the user to determine up to 10 routing states to save in memory.

#PSASRS_param1_param2_param3_param4_param5_param6_param7_param8_param9\r

Parameter	Name	Value
1	Routing state	[0:9]
2	Input route to MONITOR A	[1:8]
3	Input route to MONITOR B	[1:8]
4	Input route to MONITOR C	[1:8]
5	Input route to MONITOR D	[1:8]
6	Input route to MONITOR E	[1:8]
7	Input route to MONITOR F	[1:8]
8	Input route to MONITOR G	[1:8]
9	Input route to MONITOR H	[1:8]

Set Current Matrix As Routing State

#MSASRS_param1\r

Parameter	Name	Value
1	Routing state	[0:9]

Print Routing State Table

#PRRS\r

Mask Outputs

This function masks the output by by setting the DS HPD to low.

#MASK_param1[_param2][_param3][_param4][_param5]
[_param6][_param7][_param8]\r

Parameter	Name	Value
1 (2-8 optionally)	MONITOR	[A : H]

APPENDIX B

Unmask Masked Outputs

This function unmask outputs that were masked by "#MASK"

```
#UNMASK_param1[_param2][_param3][_param4][_param5]  
[_param6][_param7][_param8]r
```

Parameter	Name	Value
1 (2-8 optionally)	MONITOR	[A : H]

RMT-848IR Address

This function set the remote channel that must match the GEFEN RMT-848IR remote control.

```
#RMT_param1r
```

Parameter	Value
1	[0:3]

DS EDID Store In Locals Edid

This function reads EDID file from DS and store it in any input Locals EDID.

```
#EDIDDSTOLO_param1_param2[_param3][_param4][_param5] [_param6]  
[_param7][_param8][_param9]r
```

Parameter	Name	Value
1	MONITOR	[A:H]
2 (3-9 optionally)	INPUT	[1:8]

DS EDID Store In EDID Bank

This function reads EDID file from DS and store it in EDID bank.

```
#EDIDDSTOBA_param1_param2r
```

Parameter	Name	Value
1	MONITOR	[A:H]
2	EDID bank offset	[1:7]

APPENDIX B

EDID From Bank Store In Locals EDID

This function reads an EDID file from the EDID bank and stores it in any Input's local EDID.

```
#EDIDBATOLO_param1_param2[_param3][_param4][_param5][_param6]  
[_param7][_param8][_param9]r
```

Parameter	Name	Value
1	EDID bank offset	[1:7]
2 (3-9 optionally)	INPUT	[1:8]

Route Input DDC To Local EDID

This function routes the Input DDC to the Local EDID.

```
#DDCTOLO_param1r
```

Parameter	Name	Value
1	INPUT	[1:8]

Print DS EDID

This function reads the DS EDID file and sends it to the serial port.

```
#PRDSEDID_param1_param2r
```

Parameter	Name	Value
1	MONITOR	[A:H]
2	Send BIN file	0
	Send TXT file	1

Print Local EDID

This function reads the Input Local EDID file and sends it to the serial port.

```
#PRLOEDID_param1_param2r
```

Parameter	Name	Value
1	INPUT	[1:8]
2	Send BIN file	0
	Send TXT file	1

Print EDID Bank

This function reads the EDID file from the EDID bank and send it to the serial port.

APPENDIX B

#PRBAEDID_param1_param2\r

Parameter	Name	Value
1	EDID bank offset	[1:7]
2	Send BIN file	0
	Send TXT file	1

Print EDID Setting

This function sends the EDID setting table to the serial port.

#PRSEEDID\r

Load EDID To Locals EDID

These functions will load an EDID file through the serial port and store it in any Input's Local EDID.

#LOEDIDTOLO_param1_param2_param3[_param4][_param5][_param6]
[_param7][_param8][_param9][_param10]\r

Parameter	Name	Value
1	Semi echo mode	0
	Full echo mode	1
2	EDID.bin file (256 bytes)	1
	EDID.bin file (256 bytes)	2
3 (4-10 optionally)	INPUT	[1:8]

Load EDID To EDID Bank

This function loads and EDID through the serial port and store it in the EDID bank.

#LOEDIDTOBA_param1_param2\r

Parameter	Name	Value
1	Semi echo mode	0
	Full echo mode	1
2	EDID.bin file (256 bytes)	1
	EDID.bin file (256 bytes)	2
3	EDID bank offset	[1:7]

APPENDIX B

Set Output Pre Emphasis

This function will set output Pre Emphasis in db.

#PE_param1_param2\r

Parameter	Name	Value
1	MONITOR	[A:H]
2	Pre Emp. level [db]	[0,2,4,6]

Set Default Setting

This function will set the product back to its default setting.

1. Routing state will be INPUT1-MONA, INPUT2-MONB, ...,
2. All the features with default to how the hardware switches are set.

#DEF\r

SPECIFICATIONS

Video Amplifier Bandwidth	165 MHz per channel
Single Link Range	1080p (HDTV) / 1920x1200 (PC)
Input Video Signal	1.2 Volts p-p
Input DDC Signal	5 Volts p-p (TTL)
Remote Control Ports	One RS232 female, One mini-stereo
Rack mountable	2U rack space, rack ears included
DVI Connector	DVI-I 29 Pin Female (digital only)
Power Supply	24V DC
Power Consumption	60 Watts (max)

WARRANTY

Gefen warrants the equipment it manufactures to be free from defects in material and workmanship.

If equipment fails because of such defects and Gefen is notified within two (2) years from the date of shipment, Gefen will, at its option, repair or replace the equipment, provided that the equipment has not been subjected to mechanical, electrical, or other abuse or modifications. Equipment that fails under conditions other than those covered will be repaired at the current price of parts and labor in effect at the time of repair. Such repairs are warranted for ninety (90) days from the day of reshipment to the Buyer.

This warranty is in lieu of all other warranties expressed or implied, including without limitation, any implied warranty or merchantability or fitness for any particular purpose, all of which are expressly disclaimed.

1. Proof of sale may be required in order to claim warranty.
2. Customers outside the US are responsible for shipping charges to and from Gefen.
3. Copper cables are limited to a 30 day warranty and cables must be in their original condition.

The information in this manual has been carefully checked and is believed to be accurate. However, Gefen assumes no responsibility for any inaccuracies that may be contained in this manual. In no event will Gefen be liable for direct, indirect, special, incidental, or consequential damages resulting from any defect or omission in this manual, even if advised of the possibility of such damages. The technical information contained herein regarding the features and specifications is subject to change without notice.

For the latest warranty coverage information, please visit Gefen's Warranty web page at <http://www.gefen.com/kvm/aboutus/warranty.jsp>

PRODUCT REGISTRATION

Please register your product online by visiting Gefen's web site at <http://www.gefen.com/kvm/Registry/Registration.jsp>

* ma - HDMI - 848*

Rev B

20600 Nordhoff St., Chatsworth CA 91311

1-800-545-6900 818-772-9100 fax: 818-772-9120

www.gefen.com support@gefen.com

